

BEFORE START	
COCKPIT PREP.....	COMPLETED (BOTH)
GEAR PINS and COVERS.....	REMOVED
SIGNS.....	ON/AUTO
ADIRS.....	NAV
FUEL QUANTITY.....	KG.LB
TO DATA.....	SET
BARO REF.....	SET (BOTH)
WINDOWS/DOORS.....	CLOSED (BOTH)
BEACON.....	ON
THR LEVERS.....	IDLE
PARKING BRAKE.....	AS RQRD
AFTER START	
ANTI ICE.....	AS RQRD
ECAM STATUS.....	CHECKED
PITCH TRIM.....	% SET
RUDDER TRIM.....	ZERO
BEFORE TAKEOFF	
FLIGHT CONTROLS.....	CHECKED (BOTH)
FLT INST.....	CHECKED (BOTH)
BRIEFING.....	CONFIRMED
FLAP SETTING.....	CONF (BOTH)
V1. VR. V2/FLX TEMP.....	(BOTH)
ATC.....	SET
ECAM MEMO.....	TO NO BLUE
- AUTO BRK MAX	
- SIGNS ON	
- CABIN READY	
- SPLRS ARM	
- FLAPS TO	
- TO CONFIG NORM	
TAKEOFF RWY.....	CONFIRMED (BOTH)
CABIN CREW.....	ADVISED
TCAS.....	TA OR TA/RA
ENG MODE SEL.....	AS RQRD
PACKS.....	AS RQRD
AFTER TAKEOFF / CLIMB	
LDG GEAR.....	UP
FLAPS.....	RETRACTED
PACKS.....	ON
BARO REF.....	SET (BOTH)

APPROACH	
BRIEFING.....	CONFIRMED
ECAM STATUS.....	CHECKED
SEAT BELTS.....	ON
BARO REF.....	SET (BOTH)
MINIMUM.....	SET (BOTH)
ENG MODE SEL.....	AS RQRD
LANDING	
CABIN CREW.....	ADVISED
A/THR.....	SPEED/OFF
AUTOBRAKE.....	AS RQRD
ECAM MEMO.....	LDG NO BLUE
- LDG GEAR DN	
- SIGNS ON	
- CABIN READY	
- SPLRS ARM	
- FLAPS SET	
AFTER LANDING	
FLAPS.....	RETRACTED
SPOILERS.....	DISARMED
APU.....	START
RADAR.....	OFF
PREDICTIVE WINDSHEAR SYSTEM.....	OFF
PARKING	
APU BLEED.....	ON
ENGINES.....	OFF
SEAT BELTS.....	OFF
EXT LT.....	AS RQRD
FUEL PUMPS.....	OFF
PARK BRK and CHOCKS.....	AS RQRD
Consider HEAVY RAIN	
SECURING THE AIRCRAFT	
ADIRS.....	OFF
OXYGEN.....	OFF
APU BLEED.....	OFF
EMER EXIT LT.....	OFF
SIGNS.....	OFF
APU AND BAT.....	OFF
Consider COLD WEATHER	

A320

TAKEOFF CG 14/1718 20 22 24 26 28 30 32 34 36 38 40/43

TRIM POS

3.8

3

2

1

0

1

2

2.5

NOSE UP

NOSE DOWN